

# LP Morgan **CineTheatre Club**

---

## **Lounge Manual**

---



## Table of contents

To the owner	3
Installing the back support	4
Joining two seats	5
Joining three seats	6
Joining four seats	7
Leather care	8
Warranty information	9

Information in this document is subject to change without notice.

© Herma Technologies. All rights reserved.

This document is protected against unauthorised copying electronic or otherwise.

Trademarks used in this text: Herma, the Herma Logo, Galleria, LP Morgan and LP Morgan logo are registered trademarks of Herma Technologies.

Other trademarks and trade names used in this document remain the property of the relevant owners.

August 2011 Version 1.3

# LP Morgan CineTheatre Club Lounge Manual

---

## To the owner

Congratulations on purchasing an LP Morgan CineTheatre Club Lounge.

Please take a moment to review this manual, as it will ensure you many years of trouble-free service from your new CineTheatre Club Lounge.

## Please read this instruction manual before installing

The LP Morgan CineTheatre Club Lounge is designed to be modular to allow for you to configure the exact seating requirements for your home theatre clients.


## LP Morgan CineTheatre Club Lounge Features

- Multiple seat configurations. The individual seats are joined by a wedge to create that real in the round theatre experience.
- Fully motorised reclining mechanism.
- LP Morgan Club Lounge features a two stage reclining process; stage one the foot stool extends, then stage two the back seat reclines.
- When fully extended the back of the seat requires an additional 175mm of space and in front an additional 550mm of space.

## Installing the back support

After unpacking the LP Morgan CineTheatre Club Lounge locate the seat back support.


Align the locking mechanism positioned at bottom of the back support, with metal post located at the back of the chair. Then lock it by pushing the back support downward as shown in Figure 1.



**Figure 1**

## Joining two seats


*Step 1.* Locate the locking mechanism at the side of the SINGLE ARM seat. Then align and insert it to the joining DOUBLE ARM-ONE WEDGE seat.




*Step 2.* Under the seat locate the DIN plug and connect it to the controller cable.



*Step 3.* Each lounge has its own individual power supply which needs to be connected to the Plug Pack and plugged into AC power.




*Step 4.* Install the back supports. (See **Figure 1** on page 4).



## Joining three seats


*Step 1.* Locate the locking mechanism at the side of the SINGLE WEDGE ARM seat. Align and insert it to the joining DOUBLE ARM-ONE WEDGE seat. Then locate the locking mechanism of SINGLE ARM SEAT, and join it to the two connected seats.



*Step 2.* Under the seat locate the Line DIN plug and connect it to the socket of the joining seat.




*Step 3.* Install the back supports. (See Figure 1 on page 4).



## Joining four seats


*Step 1.* Locate the locking mechanism at the side of the SINGLE WEDGE ARM seat. Align and insert it to the joining DOUBLE ARM-ONE WEDGE seat. Perform the same action on the other SINGLE WEDGE ARM seats and SINGLE ARM SEATS to connect the four seats.



*Step 2.* Under the seat locate the Line DIN plug and connect it to the socket of the joining seat.



*Step 3.* Install the back supports. (See Figure 1 on page 4).



## Leather care

One of most important things to do is to clean your furniture regularly, if possible every week by simply wiping with a soft, clean cloth.

Vacuuming with a soft brush extension on your vacuum, and dusting the couch monthly, or more frequently, is a good idea.

Wipe it down with leather cleaner and treat any stains promptly in order to keep the leather couch looking its best.

To avoid squeaky surplus noise when the lounges are in motion, it may be necessary to treat area of the couch where the leather rubs against leather with protectants such as: Leather Polish, Armor All, Bee's wax, Silicon spray, etc.)



## Warranty Information

### Keep your original receipt of purchase.

Please fill out the online warranty form in order to qualify for the manufacturer's warranty.

<http://www.lpmorgan.com.au/owners.html>

The warranty covers defects in workmanship and materials, provided this product has been installed in a normal environment and maintained according to the written instructions. Herma warrants the product against loss of usefulness, discolouration or deterioration of optical quality within the warranty period as a result of manufacturing or material defects. This warranty applies only within Australia.

### Conditions

All costs related to installation and re-installation of the Herma equipment covered by this warranty are not the responsibility of Herma Technologies.

Herma will not be responsible for any consequential damages or costs resulting from, during or following installation procedures.

Herma will repair or replace, with the least possible delay, any defective equipment. Any equipment replaced pursuant to the terms of this warranty shall be retained by Herma.

The user is responsible for any freight costs relating to repair or replacement.

The Product must be returned to Herma in suitable packing to prevent damage in transit. Herma will not accept any responsibility for damage to the equipment caused by inadequate or unsuitable packing, or for any damage howsoever caused whilst the goods are in transit.

Herma Technologies shall not be liable for any injury, loss or damage, direct or consequential, arising out of the use of, misuse of, or inability to use, the equipment.

The warranty does not cover any equipment, which has been subjected to misuse, abuse, neglect, accident or intentional damage, improper voltage or any alteration which affects the reliability or performance of the equipment not attributable to faulty manufacture, parts or labour and without limiting the generality of the foregoing.

This warranty does not cover any equipment where usage, adaptation or installation (including wiring of electrical connections) are not in accordance with our written installation and operating instructions.

### Warranty Period:

One year from date of installation, not to exceed 15 months from date of invoice.

**For more information on our range of products,  
please visit [www.lpmorgan.com.au](http://www.lpmorgan.com.au), or contact  
your local LP Morgan Retailer.**

---

Factory 4a, 6 Albert Street Preston Vic 3072

**Phone:** +61 3 9480 6233 **Fax:** +61 3 9480 6533

**Email:** [info@herma.com.au](mailto:info@herma.com.au) [www.lpmorgan.com.au](http://www.lpmorgan.com.au)

August 2011 Version 1.3

